TROUBLESHOOTING:

	Possible Cause	Corrective Action
Bulb will not light	1. Bulb is burned out	1. Replace light bulb
	2. Power is off	2. Make sure power is on
	3. Faulty wire connection	3. Check wiring
Fuse blows or circuit breaker trips when light is turned on	Crossed wires or power wire is grounding out	Check wire connections

PRODUCT MAINTENANCE:

1. To clean the outside of the lamp, use a dry or slightly dampened clean cloth (use clean water, never a solvent) to wipe the shade and surface of the lamp.

2. To clean the inside of the fixture, first disconnect power to the fixture by turning off the circuit breaker or by removing the fuse at the fuse box. Next, use a dry or slightly dampened clean cloth (use clean water, never a solvent) to wipe the inside shade and interior surface of the fixture.

3. Do not use any cleaners with chemicals, solvents or harsh abrasives. Use only a dry soft cloth to dust or wipe carefully.

LIMITED WARRANTY

The manufacturer warrants this lighting fixture to be free from defects in materials and workmanship for a period of five (5) years from date of purchase. This warranty applies only to the original consumer purchaser and only to products used in normal use and service. If this product is found to be defective, the manufacturer's only obligation, and your exclusive remedy, is the repair or replacement of the product at the manufacturer's discretion, provided that the product has not been damaged through misuse, abuse, accident, modifications, alterations, neglect or mishandling. This warranty shall not apply to any product that is found to have been improperly installed, set-up, or used in any way not in accordance with the instructions supplied with the product. This warranty shall not apply to a failure of the product as a result of an accident, misuse, abuse, negligence, alteration, or faulty installation, or any other failure not relating to faulty material or workmanship. This warranty shall not apply to the finish on any portion of the product, such as surface and/or weathering, as this is considered normal wear and tear. **The manufacturer does not warrant and specially disclaims any warranty, whether express or implied, of fitness for a particular purpose, other than the warranty contained herein. The manufacturer specifically disclaims any liability and shall not be liable for any consequential or incidental loss or damage, including but not limited to any labor expense costs involved in the replacement or repair of said product.**

HOME
DECORATORS
COLLECTION

INTERIOR 1 LIGHT PENDANT
DENHOLM

HOME DEPOT SKU 529-944 (UPC 773546217187)
BRONZE FINISH



INSTRUCTION MANUAL

Thank you for purchasing this Home Decorators Collection Lighting. This product has been manufactured with the highest standards of safety and quality.

FEATURES:

Pendant can be installed at normal ceiling heights or over high ceilings using one to four standard 12” metal rods (included).

QUESTIONS, PROBLEMS, MISSING PARTS:

Before returning to your local Home Depot, please call our Customer Service Team at 1-877-527-0313 or visit www.homedepot.com. Please reference your **SKU 529-944 or (UPC 773546217187).**

CAUTION:

1. Before starting installation of this fixture or removal of a previous fixture, disconnect the power by turning off the circuit breaker or by removing the fuse at the fuse box.

2. CONSULT A QUALIFIED ELECTRICIAN IF YOU HAVE ANY ELECTRICAL QUESTIONS.

3. If you have any non-electrical question about this fixture, please contact our Customer Service Team at 1-877-527-0313 or visit www.homedepot.com. Please reference your **SKU 529-944 or (UPC 773546217187).**

4. Keep your receipt and these Instructions for Proof of Purchase.

INSTALLATION:



Figure #1



ADDITIONAL PARTS FOR INSTALLATION (included):



2. Cross Bar



3. Outlet Box Screw (x2)

4. Wire Nut (x3)

5. Canopy

6. Ground Screw



7. Mounting Screw (x2)

8. Finishing Nut (x2)

INSTALLATION INSTRUCTIONS:

1. Turn off power at main fuse box.
2. Attach the mounting screws (7) to the universal cross bar (2).
3. Mount the cross bar (2) to the junction box (1) using the two outlet box screws (3) provided, with the grounding screw (6) facing downwards.
4. Connect the white wire from the fixture to the white wire from the junction box (1) using one wire connector and reinforce this connection by wrapping electrical tape around this junction box (1). (Ref. to Figure #1)
5. Repeat Step 3 above for the black wires coming from the fixture and the junction box (1).
6. Connect the copper grounding wire from the fixture and from the junction box (1) to the grounding screw (6) on the universal cross bar (2). (Ref. to Figure #1)

Note: If you have questions that are electrical in nature, consult your local electrical code or a qualified electrician for approved grounding methods.

7. Push all electrical wires and connections well into the junction box, ensuring that the wires and connections are not damaged.
8. Push the canopy (5) to the ceiling aligning its holes with the mounting screws (7) and hold it in place flush with the ceiling using the finishing nuts (8).
9. Installation is complete, after completing Steps 6 and 7 of the assembly instructions as shown on page 4.
10. Turn ON the power at the circuit breaker of fuse box.
11. Turn the light switch ON, to activate the fixture.

TOOLS REQUIRED FOR ASSEMBLY & INSTALLATION (not included):

Safety goggles

Chain Pliers

Wire Strippers



Wire Cutters



Flathead Screwdriver



Phillips Screwdriver



Electrical Tape

A19 Bulb 60W max. (not included)

ADDITIONAL PARTS FOR ASSEMBLY (included):

9. Retaining Screw

10. Decorative Rod Finial



11. Fabric Shade



12. Socket Ring

ASSEMBLY INSTRUCTIONS:

1. Carefully unpack the fixture. Lay out all parts on a clean surface.
2. Screw-in tightly and attach the 12” rod, followed by the decorative rod finial (10), to the fixture body.
3. Tighten the retaining screw (9) to hold the end-piece (part of fixture body) to the top-most 12” rod (part of fixture body).

SHADE AND BULB INSTALLATION:

1. Secure each fabric shade (11) to each socket on fixture main body.
2. Once the fixture is installed in place, install 60W A19 bulbs (maximum, not included) into each socket (part of fixture body).

ASSEMBLY:


5. Canopy
8. Finishing Nut (x2)
9. Retaining Screw
Rod 12” (Part of Fixture body)
Rod 12” (Part of Fixture body)
Rod 12” (Part of Fixture body)
10. Decorative Rod Finial
Rod 12” (Part of Fixture body)
Fixture Main Body
11. Fabric Shade
12. Socket Ring
60W A19 Bulb (not included)